

Einbaumaß (135mm, 142mm, 148mm)
 Frame spacing (135mm, 142mm, 148mm)



32-Loch Gehäuse Speichenlänge
32-hole Hub-shell Spoke lengths

Laufradgröße / Wheel Size	Anzahl Kreuzungen / Number of Spoke Crosses	ERD*	32-Loch Speichenlänge / 32-hole Spoke lengths	
18"	1-X	341-343	128	
		344	130	
20"	1-X	372-373	142	
		374-377	144	
		378-381	146	
		382-385	148	
		386-389	150	
		390-394	152	
24"	1-X	472-476	192	
		477-480	194	
		481-484	196	
		485-489	198	
		490-493	200	
		494-497	202	
		498-501	204	
		502-503	206	
		26"	2-X	516-519
520-523	228			
524-527	230			
528-531	232			
532-535	234			
536-539	236			
540-543	238			
544-547	240			
548-551	242			
650B	2-X		552-555	244
			556-559	246
			560-563	248
			564-567	250
			568-571	252
			572-575	254
			576-579	256
			580-583	258
			28"	2-X
588-592	262			
593-596	264			
597-600	266			
601-604	268			
605-608	270			
29"	2-X	609-612	272	
		613-616	274	
		617-620	276	
		621-624	278	
		625-628	280	
		629-632	282	

36-Loch Gehäuse Speichenlänge
36-hole Hub-shell Spoke lengths

Laufradgröße / Wheel Size	Anzahl Kreuzungen / Number of Spoke Crosses	ERD*	36-Loch Speichenlänge / 36-hole Spoke lengths	
18"	1-X	341-342	126	
		343-344	128	
20"	1-X	372-375	142	
		376-379	144	
		380-383	146	
		384-387	148	
		388-392	150	
		393-396	152	
24"	1-X	472-474	190	
		475-478	192	
		479-482	194	
		483-486	196	
		487-490	198	
		491-494	200	
		495-498	202	
		499-502	204	
		503	206	
26"	2-X	516-517	222	
		518-522	224	
		523-526	226	
		527-530	228	
		531-534	230	
		535-538	232	
		539-542	234	
		543-546	236	
		547-550	238	
	650B	2-X	551-554	240
			555-558	242
			559-562	244
			563-566	246
			567-570	248
			571-574	250
			575-578	252
			579-582	254
			28"	2-X
587-590	258			
591-594	260			
595-598	262			
599-602	264			
603-607	266			
29"	2-X	608-611	268	
		612-615	270	
		616-619	272	
		620-623	274	
		624-627	276	
		628-631	278	

empfohlene Größe / recommended rim size



36-Loch ab Serien Nr.: silber/silver > 159293
 36-hole from Serial-No.: schwarz/black > 159308
 rot/red > 155001

* ERD Messung - siehe Rohloff Handbuch 'Bestimmen des Felgeninnendurchmessers'.

* ERD Measurement - please refer to the Rohloff SPEEDHUB Owners Manual - 'Determining the effective rim diameter'.

V03-2019 - Technische Änderungen vorbehalten. Rohloff reserve the right to change technical specifications without prior warning.

